

Kinetex® wall base is a unique textile composite product with specific installation techniques.

The Kinetex Installation Instructions and Kinetex Maintenance Instructions are available electronically. Should you like a copy, please contact **Marketing Services** at 800.241.4586, extension 8020. For further questions or additional information, **J+J Flooring Customer Relations** can be reached at 800.241.4586.

### **Site and Modular Material Conditioning/Surface Preparation**

The temperature in the area Kinetex Wall Base is to be installed, should be maintained at 60 degrees F or greater for at least 24 hours before and after installation.

The surface to which Kinetex Wall Base is to be applied must be completely dry, and clean of all foreign materials, such as dust, dirt, etc..

### **Installation**

Kinetex Wall Base adheres to the wall using a pressure sensitive adhesive, therefore 15 lbs. per inch of pressure must be applied for proper adhesion.

To begin installation, remove 12 inches of paper, revealing the adhesive, and apply to the surface being sure to rest the bottom edge of Kinetex Base on the floor.

Unroll the base in short lengths, remove paper, and press against wall using adequate pressure.

Staples should be used at all ends, and on inside and outside corners, placed underneath the edge of the binding tape.

A stair tool can be used to tuck base into corners.

Kinetex Wall Base may not adhere to some silicon wallpaper.

*Kinetex Wall Base has a shelf life of six months when stored at 75 degrees F, and 50% relative humidity or less.*

THE FOLLOWING CONDITIONS MAY IMPACT THE ADHESION:

Abnormal exposure to cleaning chemicals.

Soaking the base with any fluid, standing water, floods, etc.

If base is exposed to unusually hot temperatures.

### **Tools**

Steel measuring tape, knife, stair tool.