

DUE TO THE UNIQUE VISUAL CHARACTERISTICS OF MODULAR CARPETS, SEAM VISIBILITY, PATTERN REPEATS AND PATTERN RUN-OFF APPEAR MORE NOTICEABLE THAN IN BROADLOOM CARPETS. SUCH VISUAL CHARACTERISTICS DO NOT CONSTITUTE A MANUFACTURING DEFECT, AND AS SUCH, SHOULD BE CONSIDERED WHEN SELECTING MODULAR CARPET AND ITS INSTALLATION METHOD(S). IT IS STRONGLY RECOMMENDED THAT YOU CHECK THE INSTALLATION METHOD FOR APPROVAL BEFORE PROCEEDING.

J+J FLOORING GROUP, EF CONTRACT AND PENTZ COMMERCIAL REQUIRES THAT THE CARPET BE INSPECTED PRIOR TO INSTALLATION FOR PROPER STYLE, COLOR AND POTENTIAL DEFECTS. NO CLAIMS WILL BE HONORED IF THE CARPET IS INSTALLED WITH VISIBLE DEFECTS. SHOULD THERE BE A PROBLEM, CALL J+J FLOORING GROUP CUSTOMER RELATIONS DEPARTMENT AT 800.241.4586 , EF CONTRACT CUSTOMER RELATIONS AT 800.451.1250 OR PENTZ TECHNICAL SERVICE AT 866.706.9745 X8407.

SITE AND MODULAR MATERIAL CONDITIONING - The building must be enclosed and the HVAC in continuous operation. Modules must be conditioned to room temperature for 48 hours prior to installation. The ambient air relative humidity must be between 10% - 65% with a floor and room temperature between 65 – 95 degrees Fahrenheit. These conditions must be maintained for a minimum of 48 hours prior to installation and at least 48 hours after completion of the installation.

SURFACE PREPARATION - Dust, dirt, debris and non-compatible adhesive must be removed before the installation begins. Surfaces must be smooth and level with all holes and cracks 1/8 inch or wider filled with Portland cement-based patch reinforced with polymers or primed with Commercialon® Premium Sealer. For complete information refer to ACI Concrete 302.104R Report.

LATEX OR OLD ADHESIVES - Must be mechanically scraped down to a bare residue flat with the concrete substrate or covered with a skim coat of Portland cement-based patch reinforced with polymers. Any old adhesive residue must also be covered with Commercialon Premium Sealer. Note: Failure to remove or seal dissimilar adhesives may cause installation failure, plasticizer migration, shifting, buckling or edge curling; these conditions will not be covered under warranty.

CONCRETE MOISTURE TESTING and pH Testing - Substrate surfaces must be tested for moisture. It is the responsibility of the owner or owner's representative to perform moisture testing prior to starting the installation. ASTM F 2170-2 relative humidity probe moisture testing is required. Acceptable relative humidity testing results are up to 90% RH. Alkalinity tests should also be performed per ASTM F 710. The maximum acceptable pH is 9.0. For test results that determine 90% - 97% RH or pH readings of 9.0 – 11.00, Commercialon Premium Sealer is required.

SUBFLOORS

New Concrete – New concrete must be fully cured and free of moisture (see ASTM F 2170-2). New concrete requires a curing period of approximately 90 days. For complete information, refer to CRI – 104 Installation Standard.

Old Concrete – Old concrete must be checked for moisture. Dry, dusty, porous floors must be primed or encapsulated with Commercialon Premium Sealer; Note: primers will not correct a moisture problem. For complete information, refer to CRI – 104 Installation Standard.

Wood – Wood floors must be smooth, level and APA floor grade. If the floor is uneven, an approved underlayment will be required. Old finishes must be tested for compatibility with adhesives or removed and porous wood primed with Commercialon Premium Sealer.

Terrazzo / Marble – Level all grout lines with Portland cement-based patch reinforced with polymers. Glossy surfaces must be sanded for adhesive bond. Waxes and similar finishes must be removed.

Hard Surfaces – Tiles must be well secured to the floor or removed. Broken, damaged, or loose tiles must be replaced. Waxes and similar finishes must be removed from VCT before applying adhesive. Existing sheet vinyl is not a suitable substrate for modular installation and must be removed.

OLD CARPET – Remove old carpet adhesives by scraping or other mechanical means. Remove existing adhesives to bare residue. When adhesives are dissimilar, Commercialon Premium Sealer is required.

FULL SPREAD ADHESIVE SYSTEM – A full spread adhesive system is required for installation of Nexus Modular (carpet tile). Fully spread Commercialon® Premium Modular Pressure Sensitive Adhesive using a 1/16 x 1/32 x 1/32 "U" notch trowel or spread using a 3/8" nap or foam paint roller. Keep the roller saturated and wet with adhesive throughout the installation in order to maintain a constant spread rate. Allow to completely dry so adhesive does not transfer when touched. The spread rate for Commercialon Premium Modular Adhesive is approximately 1,080 square feet per four gallon bucket. Inadequate amounts of adhesive can cause modules to shift and move and will not be covered under warranty. Warranty coverage requires the use of Commercialon Premium Modular Adhesive. Failure to use Commercialon Premium Modular Adhesive will reduce Lifetime Material Warranty to one year. J+J Flooring Group or Pentz Commercial will not be responsible for the adhesive bond where other adhesives have been used.

TILE PLACEMENT - Arrows are embossed or printed on the module backing to show pile direction. To ensure proper alignment, check spacing every ten modules. Measure ten modules; proper spacing should be within ¼ inch. Continue to check spacing every ten modules throughout the entire installation.

Due to the unique visual characteristics of modular carpets, pattern repeats, pattern run-off, seams may appear more noticeable than in broadloom carpets. Such visual characteristics do not constitute a manufacturing defect, and as such, should be considered when selecting modular carpet and its installation. Tolerance for off register is ¼" maximum (approx. 1.5 stitch rows).

PALLET AND BUNDLE SEQUENCING - It is very important to install carpet modules in the order they were manufactured; this is easily accomplished by selecting pallets in sequential order and following the numbers located on each bundle. Typically, an installation will begin with the lowest bundle numbers and progress through the highest numbers until the project is complete. Installing modules by bundle sequence will assure the most even uniform look possible.

FLATWIRE CABLE / TRENCH HEADERS - Cable should be centered under modules and no adhesive used unless approved by the manufacturer. Trench headers require a control grid of adhesive on either side of header panels to prevent movement. It is highly recommended that these areas be installed ashlar.

STAIRS - Use single or double undercut stair nosing and cut tiles to fit nosing, both step and riser. Use full spread adhesive under modules.

FINISHED INSTALLATION - Roll entire job with 75-100 lb. roller after completion of installation.

LOOP PILE CONSTRUCTION – Carpet modules with loop pile constructions may experience yarn blossoming at the edges, which is consistent with this type of construction. Clipping or shearing the yarn edges can remedy this condition.

REPLACEMENT TILES - On occasion, it may be necessary to replace damaged or heavily soiled modules. Modules can be replaced with new modules from onsite inventory or from another area of the installation. A difference of appearance may be noticed when modules are replaced; this difference usually diminishes in a short time.

The procedures listed above are our best recommendations for installing Nexus Modular Carpets. If you have further questions or require additional information please contact:

For J+J Flooring Group products: J+J Flooring Group Customer Relations Department at 800-241-4586 For

EF Contract products: EF Contract Customer Relations Department at 800-451-1250

For Pentz products: Pentz Technical Service at 866-706-9745 x8407 or email pentztechservice@engineeredfloors.com